

神牛X系列引闪器与品牌相机兼容列表

尼康相机兼容性列表

XPRO II N、X2T-N、Xpro-N、X1N 主控从属闪光灯

相机型号	相机款式	TTL闪光控制			M闪光控制			重复闪光	AF辅助对焦灯	备注
		标准	REAR	HSS(FP)	标准	REAR	HSS(FP)			
D800	单反相机	✓	✓	✓	✓	✓	✓	✓	✓	
D780		✓	✓	✓	✓	✓	✓	✓	✓	
D5		✓	✓	✓	✓	✓	✓	✓	✓	
D4		✓	✓	✓	✓	✓	✓	✓	✓	
D500		✓	✓	✓	✓	✓	✓	✓	✓	
D610		✓	✓	✓	✓	✓	✓	✓	✓	
D750		✓	✓	✓	✓	✓	✓	✓	✓	
D700		✓	✓	✓	✓	✓	✓	✓	✓	
D300S		✓	✓	✓	✓	✓	✓	✓	✓	
D3300		✓	✓	✓	✓	✓	✓	✓	✓	
D3100		✓	✓	✓	✓	✓	✓	✓	✓	
D5300		✓	✓	✓	✓	✓	✓	✓	✓	
D5200		✓	✓	✓	✓	✓	✓	✓	✓	
D5000		✓	✓	✓	✓	✓	✓	✓	✓	
Z7II	微单相机	✓	✓	✓	✓	✓	✓	✓	✓	
Z6		✓	✓	✓	✓	✓	✓	✓	✓	
Z8		✓	✓	✓	✓	✓	✓	✓	✓	
Z9		✓	✓	✓	✓	✓	✓	✓	✓	
ZFC		✓	✓	✓	✓	✓	✓	✓	✓	

备注：使用高速注意相机设置为高速自动快门。

X3 N主控从属闪光灯

相机型号	相机款式	TTL闪光控制			M闪光控制			重复闪光	AF辅助对焦灯	备注
		标准	REAR	HSS(FP)	标准	REAR	HSS(FP)			
D800	单反相机	✓	✓	✓	✓	✓	✓	✓	✓	
D780		✓	✓	✓	✓	✓	✓	✓	✓	
D5		✓	✓	✓	✓	✓	✓	✓	✓	
D4		✓	✓	✓	✓	✓	✓	✓	✓	
D500		✓	✓	✓	✓	✓	✓	✓	✓	
D610		✓	✓	✓	✓	✓	✓	✓	✓	
D750		✓	✓	✓	✓	✓	✓	✓	✓	
D700		✓	✓	✓	✓	✓	✓	✓	✓	
D300S		✓	✓	✓	✓	✓	✓	✓	✓	
D3300		✓	✓	✓	✓	✓	✓	✓	✓	
D3100		✓	✓	✓	✓	✓	✓	✓	✓	
D5300		✓	✓	✓	✓	✓	✓	✓	✓	
D5200		✓	✓	✓	✓	✓	✓	✓	✓	
D5000		✓	✓	✓	✓	✓	✓	✓	✓	
Z7II	微单相机	✓	✓	✓	✓	✓	✓	✓	✓	
Z6		✓	✓	✓	✓	✓	✓	✓	✓	
Z8		✓	✓	✓	✓	✓	✓	✓	✓	
Z9		✓	✓	✓	✓	✓	✓	✓	✓	
ZFC		✓	✓	✓	✓	✓	✓	✓	✓	

备注：使用高速注意相机设置为高速自动快门。

宾得相机兼容性列表

XProP引闪器主控从属闪光灯

相机型号	相机款式	TTL闪光控制			M闪光控制			重复闪光	AF辅助对焦灯	备注
		标准	REAR	HSS(FP)	标准	REAR	HSS(FP)			
K-3II	新款相机	✓		✓	✓	✓	✓	✓	✓	
645Z		✓		✓	✓	✓	✓	✓	✓	
KP		✓		✓	✓	✓	✓	✓	✓	
K-70		✓		✓	✓	✓	✓	✓	✓	
K-S1		✓		✓	✓	✓	✓	✓	✓	
K-S2		✓		✓	✓	✓	✓	✓	✓	

佳能相机兼容性列表

XPRO II C、X2T-C、Xpro-C、X1C 主控从属闪光灯

相机型号	相机款式	TTL闪光控制			M闪光控制			重复闪光	Gr单组模式相机设置	AF辅助对焦灯	备注
		标准	REAR	HSS(FP)	标准	REAR	HSS(FP)				
5DIII	单反相机	✓	✓	✓	✓	✓	✓	✓	✓	✓	
5DIV		✓	✓	✓	✓	✓	✓	✓	✓	✓	
70D		✓	✓	✓	✓	✓	✓	✓	✓	✓	
80D		✓	✓	✓	✓	✓	✓	✓	✓	✓	
1DX		✓	✓	✓	✓	✓	✓	✓	✓	✓	
850D		✓	✓	✓	✓	✓	✓	✓	✓	✓	
760D		✓	✓	✓	✓	✓	✓	✓	✓	✓	
5DII		✓	✓	✓	✓	✓	✓	✓	✓	✓	
7DII		✓	✓	✓	✓	✓	✓	✓	✓	✓	
6DII		✓	✓	✓	✓	✓	✓	✓	✓	✓	
6D		✓	✓	✓	✓	✓	✓	✓	✓	✓	
800D		✓	✓	✓	✓	✓	✓	✓	✓	✓	
90D		✓	✓	✓	✓	✓	✓	✓	✓	✓	
600D		✓	✓	✓	✓	✓	✓	✓	✓	✓	
7D		✓	✓	✓	✓	✓	✓	✓	✓	✓	
200DII	微单相机	✓	✓	✓	✓	✓	✓	✓	✓	✓	
3000D		✓	✓	✓	✓	✓	✓	✓	✓	✓	
1500D		✓	✓	✓	✓	✓	✓	✓	✓	✓	
M5		✓	✓	✓	✓	✓	✓	✓	✓	✓	
M3		✓	✓	✓	✓	✓	✓	✓	✓	✓	
EOS RP	微单相机	✓	✓	✓	✓	✓	✓	✓	✓	✓	
EOS R		✓	✓	✓	✓	✓	✓	✓	✓	✓	
R5		✓	✓	✓	✓	✓	✓	✓	✓	✓	
R6II		✓	✓	✓	✓	✓	✓	✓	✓	✓	
R7		✓	✓	✓	✓	✓	✓	✓	✓	✓	
R50		✓	✓	✓	✓	✓	✓	✓	✓	✓	
R3		✓	✓	✓	✓	✓	✓	✓	✓	✓	

备注：使用高速注意相机设置为高速自动快门。
不支持
快门1/250高速存在暗边。
加转接座才能与引闪器使用。

X3 C主控从属闪光灯

相机型号	相机款式	TTL闪光控制			M闪光控制			重复闪光	Gr单组模式相机设置	备注
		标准	REAR	HSS(FP)	标准	REAR	HSS(FP)			
5DIII	单反相机	✓	✓	✓	✓	✓	✓	✓	✓	
5DIV		✓	✓	✓	✓	✓	✓	✓	✓	
70D		✓	✓	✓	✓	✓	✓	✓	✓	
80D		✓	✓	✓	✓	✓	✓	✓	✓	
1DX		✓	✓	✓	✓	✓	✓	✓	✓	
850D		✓	✓	✓	✓	✓	✓	✓	✓	
760D		✓	✓	✓	✓	✓	✓	✓	✓	
5DII		✓	✓	✓	✓	✓	✓	✓	✓	
7DII		✓	✓	✓	✓	✓	✓	✓	✓	
6DII		✓	✓	✓	✓	✓	✓	✓	✓	
6D		✓	✓	✓	✓	✓	✓	✓	✓	
800D		✓	✓	✓	✓	✓	✓	✓	✓	
90D		✓	✓	✓	✓	✓	✓	✓	✓	
600D		✓	✓	✓	✓	✓	✓	✓	✓	
7D		✓	✓	✓	✓	✓	✓	✓	✓	
200DII	微单相机	✓	✓	✓	✓	✓	✓	✓	✓	
3000D		✓	✓	✓	✓	✓	✓	✓	✓	
1500D		✓	✓	✓	✓	✓	✓	✓	✓	
M5		✓	✓	✓	✓	✓	✓	✓	✓	
M3		✓	✓	✓	✓	✓	✓	✓	✓	
EOS RP	微单相机	✓	✓	✓	✓	✓	✓	✓	✓	
EOS R		✓	✓	✓	✓	✓	✓	✓	✓	
R5		✓	✓	✓	✓	✓	✓	✓	✓	
R6II		✓	✓	✓	✓	✓	✓	✓	✓	
R7		✓								

富士相机兼容性列表

XPRO II F、X2T-F、Xpro-F、X1T-F 主控从属闪光灯

相机型号	相机款式	TTL闪光控制			M闪光控制			重复闪光	AF辅助对焦灯	备注
		标准	REAR	HSS(FP)	标准	REAR	HSS(FP)			
X-Pro2	A	✓	✓	✓	✓	✓	✓	✓	✓	
X-T20		✓	✓	✓	✓	✓	✓	✓	✓	
X-T2		✓	✓	✓	✓	✓	✓	✓	✓	
X-T1		✓	✓	✓	✓	✓	✓	✓	✓	
GFX50s		✓	✓	✓	✓	✓	✓	✓	✓	
GFX50R		✓	✓	✓	✓	✓	✓	✓	✓	
X-T30		✓	✓	✓	✓	✓	✓	✓	✓	
X-T4		✓	✓	✓	✓	✓	✓	✓	✓	
X-T3		✓	✓	✓	✓	✓	✓	✓	✓	
X-T50		✓	✓	✓	✓	✓	✓	✓	✓	
X-H2		✓	✓	✓	✓	✓	✓	✓	✓	
X-Pro1		✓	✓		✓	✓		✓		
X-T10	B	✓	✓		✓	✓		✓		
X-E1		✓	✓		✓	✓		✓		
X-A3		✓	✓		✓	✓		✓		
X100F		✓	✓		✓	✓		✓		
X100T	C	✓	✓		✓	✓		✓		1. 相机没有后帘、高速模式拍摄
										2. M闪光控制，无法更改相机前帘、后帘模式，相机设置。
										不支持
										不支持
										不支持
										1. 相机没有后帘、高速模式拍摄

X3 F主控从属闪光灯

相机型号	相机款式	TTL闪光控制			M闪光控制			重复闪光	AF辅助对焦灯	备注
		标准	REAR	HSS(FP)	标准	REAR	HSS(FP)			
X-Pro2	A	✓	✓	✓	✓	✓	✓	✓	✓	
X-T20		✓	✓	✓	✓	✓	✓	✓	✓	
X-T2		✓	✓	✓	✓	✓	✓	✓	✓	
X-T1		✓	✓	✓	✓	✓	✓	✓	✓	
GFX50s		✓	✓	✓	✓	✓	✓	✓	✓	
GFX50R		✓	✓	✓	✓	✓	✓	✓	✓	
X-T30		✓	✓	✓	✓	✓	✓	✓	✓	
X-T4		✓	✓	✓	✓	✓	✓	✓	✓	
X-T3		✓	✓	✓	✓	✓	✓	✓	✓	
X-T50		✓	✓	✓	✓	✓	✓	✓	✓	
X-H2		✓	✓	✓	✓	✓	✓	✓	✓	
X-Pro1		✓	✓		✓	✓		✓		
X-T10	B	✓	✓		✓	✓		✓		
X-E1		✓	✓		✓	✓		✓		
X-A3		✓	✓		✓	✓		✓		
X100F		✓	✓		✓	✓		✓		
X100T	C	✓	✓		✓	✓		✓		1. 相机没有后帘、高速模式拍摄
										2. M闪光控制，无法更改相机前帘、后帘模式，相机设置。
										不支持
										不支持
										1. 相机没有后帘、高速模式拍摄

奥林巴斯/松下兼容性列表

X3 O、XPRO II O、X2T-O、Xpro-O、X1T-O主控从属闪光灯

相机型号	相机款式	TTL闪光控制			M闪光控制			重复闪光	AF辅助对焦灯	备注
		标准	REAR	HSS(FP)	标准	REAR	HSS(FP)			
E-M1	奥林巴斯	✓	✓	✓	✓	✓	✓	✓	✓	
PRN-F		✓	✓	✓	✓	✓	✓	✓	✓	
E-M10II		✓	✓	✓	✓	✓	✓	✓	✓	
E-M10III		✓	✓	✓	✓	✓	✓	✓	✓	
E-PL8		✓	✓	✓	✓	✓	✓	✓	✓	
E-P5		✓	✓	✓	✓	✓	✓	✓	✓	
E-M5II		✓	✓	✓	✓	✓	✓	✓	✓	
GH4		✓	✓	✓	✓	✓	✓	✓	✓	
LX100		✓	✓	✓	✓	✓	✓	✓	✓	
GF1		✓	✓	✓	✓	✓	✓	✓	✓	
G85		✓	✓	✓	✓	✓	✓	✓	✓	
GX85		✓	✓	✓	✓	✓	✓	✓	✓	高速存在亮边
FZ2500GX		✓	✓	✓	✓	✓	✓	✓	✓	高速存在亮边
S1		✓	✓	✓	✓	✓	✓	✓	✓	高速存在亮边

注：1. 此表格仅列举目前已测试的相机型号，未涵盖所有相机。其他相机型号，用户可自行测试。

2. 本公司保留未来修改此表格内容的权利。

索尼相机兼容性列表

XPRO II S、X2T-S、Xpro-S、X1S 主控从属闪光灯

相机型号	相机款式	TTL闪光控制			M闪光控制			重复闪光	AF辅助对焦灯	备注
		标准	REAR	HSS(FP)	标准	REAR	HSS(FP)			
A7III	微单相机	✓	✓	✓	✓	✓	✓	✓	✓	
A7IV		✓	✓	✓	✓	✓	✓	✓	✓	
A7R5		✓	✓	✓	✓	✓	✓	✓	✓	
A7RIII		✓	✓	✓	✓	✓	✓	✓	✓	
A7RIV		✓	✓	✓	✓	✓	✓	✓	✓	
A9		✓	✓	✓	✓	✓	✓	✓	✓	
A7RIV4.0		✓	✓	✓	✓	✓	✓	✓	✓	
A7R		✓	✓	✓	✓	✓	✓	✓	✓	
A6400		✓	✓	✓	✓	✓	✓	✓	✓	
A6700		✓	✓	✓	✓	✓	✓	✓	✓	
A6000		✓	✓	✓	✓	✓	✓	✓	✓	
RX10	固定镜头相机	✓	✓	✓	✓	✓	✓	✓	✓	
A99	单反相机	✓	✓	✓	✓	✓	✓	✓	✓	
A77		✓	✓	✓	✓	✓	✓	✓	✓	
A77II		✓	✓	✓	✓	✓	✓	✓	✓	
A350		✓	✓	✓	✓	✓	✓	✓	✓	

X3 S主控从属闪光灯

相机型号	相机款式	TTL闪光控制			M闪光控制			重复闪光	AF辅助对焦灯	备注
		标准	REAR	HSS(FP)	标准	REAR	HSS(FP)			
A7III	微单相机	✓	✓	✓	✓	✓	✓	✓	✓	
A7IV		✓	✓	✓	✓	✓	✓	✓	✓	
A7R5		✓	✓	✓	✓	✓	✓	✓	✓	
A7RIII		✓	✓	✓	✓	✓	✓	✓	✓	
A7RIV		✓	✓	✓	✓	✓	✓	✓	✓	
A9		✓	✓	✓	✓	✓	✓	✓	✓	
A7RIV4.0		✓	✓	✓	✓	✓	✓	✓	✓	
A7R		✓	✓	✓	✓	✓	✓	✓	✓	
A6400		✓	✓	✓	✓	✓	✓	✓	✓	
A6700		✓	✓	✓	✓	✓	✓	✓	✓	
A6000		✓	✓	✓	✓	✓	✓	✓	✓	
RX10	固定镜头相机	✓	✓	✓	✓	✓	✓	✓	✓	
A99	单反相机	✓	✓	✓	✓	✓	✓	✓	✓	
A77		✓	✓	✓	✓	✓	✓	✓	✓	
A77II		✓	✓	✓	✓	✓	✓	✓	✓	
A350		✓	✓	✓	✓	✓	✓	✓	✓	

X3 L主控从属闪光灯

相机型号	相机款式	TTL闪光控制			M闪光控制			重复闪光	AF辅助对焦灯	备注
		标准	REAR	HSS(FP)	标准	REAR	HSS(FP)			
SL1	新款相机	✓	✓	✓	✓	✓	✓	✓	✓	连拍存在漏闪
SL2		✓	✓	✓	✓	✓	✓	✓	✓	高速拍照存在亮边。
M10		✓	✓	✓	✓	✓	✓	✓	✓	
Q2		✓	✓	✓	✓	✓	✓	✓	✓	
TYP601										