

Godox

VSA-19K / VSA-26K / VSA-36K

LED灯聚光筒套装
Spotlight Attachment Kit

合格证
QC PASS

深圳市神牛摄影器材有限公司

地址:深圳市宝安区福海街道塘尾社区耀川工业区厂房2栋


电话:0755-29609320(8062) 传真:0755-25723423 邮箱:godox@godox.com

GODOX Photo Equipment Co., Ltd.

Add: Building 2, Yaochuan Industrial Zone, Tangwei Community, Fuhai Street, Bao'an

District, Shenzhen 518103, China Tel: +86-755-29609320(8062)

Fax: +86-755-25723423 E-mail: godox@godox.com



前言

感谢您购买神牛产品！

为了给影视创作者们提供更好的影视级灯光附件，营造更多的布光效果。神牛专门开发了一款性能强大而实用多角度聚光筒VSA。通用保荣卡口设计，可搭配众多保荣口LED灯使用。它可以为用户营造聚光、追光、光束切割、光学变焦、手动对焦、光束造型等特色光效，打造浓郁出彩的影视氛围。根据使用需求，专设三个不同的聚光筒套装：VSA-19K、VSA-26K、VSA-36K。VSA-19K配置19°可拆卸镜头，VSA-26K配置26°可拆卸镜头，VSA-36K配置36°可拆卸镜头。

关于保荣口聚光筒套装

强大的多卡槽设计，可放置切光片、光阑、投影片、色片夹等附件。

灵活易用U型支架设计，0-330°可调角度，随时随地调整光效位置。

属于专业级影视灯光附件，适用于神牛VL300、SL200II等300W以下保荣口影视灯。

灵活对焦，以改变投影光斑边缘锐利程度，进行虚实效果调节，以实现对焦效果，投入更多的影视创意。

随套装附有Gobo投影片夹、色片夹等附件，装备齐全，便利简洁。

⚠ 警告

△ 请勿私自拆卸产品，如产品出现故障须由本公司或授权的维修人员进行检查维修。

△ 本品属于精密光学机械，请勿让儿童靠近及接触本产品。

△ 搭配灯体使用时，请注意机壳高温，点亮时请勿触摸机壳，以免烫伤。

△ 若发生任何故障，待维修完成后，方可重新使用。


△ 聚光筒套装中，镜头属于易碎物品，请妥善保存，请勿随意撞击或者使其跌落。

△ 不使用时，请放置在通风干燥处，注意防潮。

△ 禁止搭配300W以上LED灯使用。

△ 搭配LED灯使用时，聚光筒壳体高温，请带厚手套操作，以免烫伤。

部件名称



01.保荣卡口	06.对焦旋钮
02.切光片卡槽	07.套筒旋钮
03.光阑卡槽	08.U型支架
04.投影片卡槽	09.固定槽推制
05.色片框固定槽	

名称	型号	标配物品
保荣口聚光筒套装	VSA-19K	聚光筒×1(含19°投影镜头)、 Gobo投影片夹×1、Gobo投影片×3 色片夹×1、便携包CB37×1、说明书×1
保荣口聚光筒套装	VSA-26K	聚光筒×1(含26°投影镜头)、 Gobo投影片夹×1、Gobo投影片×3 色片夹×1、便携包CB37×1、说明书×1
保荣口聚光筒套装	VSA-36K	聚光筒×1(含36°投影镜头)、 Gobo投影片夹×1、Gobo投影片×3 色片夹×1、便携包CB37×1、说明书×1

包装清单



可选购附件




投影片组VSA-GS1



投影片组VSA-GS2



投影片组VSA-GS3



投影片组VSA-GS4



色温调整组VSA-11T



色彩效果组VSA-11C



光伞VSA-ID




镜头手提包CB38

安装及其使用

1. 安装到三脚架上


将聚光筒放进三脚架的套筒中, 调至所需的拍摄角度, 最后旋转套筒旋钮, 锁紧固定好。



注:三脚架为另购物品, 不包含在套装内。


2. 安装保荣卡口LED影视灯

将LED影视灯保荣卡口对准聚光筒的卡入，接着向右旋转拧紧即可。



3. 拆卸保荣卡口LED摄影灯 (以SL150II为例)


将LED影视灯SL150II的卡口推制往后拉伸，接着向左旋转松开即可完成拆卸。



注：安装及拆卸LED影视灯需断电后进行。

4. 安装光阑 (另购)


先用十字螺丝刀拧松光阑槽侧边螺丝 (旋转拧松两圈即可)，接着用手指滑开光阑槽盖，最后将光阑插入光阑槽中。



⚠️ 注：光阑搭配LED影视灯使用时，仅限神牛300W(含)以下影视灯使用，如神牛SL60、SL150II、SL200II、VL150、VL200、VL300、FV150、FV200、UL60、UL150、SL100D、SL100Bi。如使用其他品牌影视灯，导致光效效果不理想或因高温带来的人身伤害，本司概不负责。

5. 安装色片 (另购)


将所需色片放进色纸夹，用手指往后推动固定槽推制后，将装有色片的色纸夹放进色片框固定槽中



⚠️ 注：色片VSA-11C、色片VSA-11T搭配LED影视灯使用时，仅限神牛300W(含)以下影视灯使用，如神牛SL60、SL150II、SL200II、VL150、VL200、VL300、FV150、FV200、UL60、UL150、SL100D、SL100Bi。如使用其他品牌影视灯或色片，发生色片被烧焦或其他人身伤害，本司概不负责。

6. 安装Gobo片

将所需Gobo片放进Gobo投影片夹中，接着将Gobo投影片放进投影片卡槽中。最后稍微用力往下压，当投影片完全插入投影片卡槽中，即表示完成Gobo片安装。



搭配VL300使用，在不同距离下的照度值




LED摄影灯	色温	聚光筒	镜头	照度单位	3m	4m	5m
VL300	5600K 100%	无	无	Lux	1380	860	602
				Fc	128.3	79.9	55.9
		有	19°投影镜头	Lux	7530	4040	2400
				Fc	699.8	375.5	223
		有	26°投影镜头	Lux	5130	2830	1720
				Fc	476.8	263	159.9
		有	36°投影镜头	Lux	4200	2330	1430
				Fc	390.3	216.5	132.9

特别说明：上述照度数据皆为平均数据，不同灯的照度数据会有微小差异。

产品尺寸及重量

聚光筒套装型号	VSA-19K / VSA-26K/VSA-36K
聚光筒产品尺寸(不包含镜头)	516*241*196mm
19°镜头尺寸、26°镜头尺寸、36°镜头尺寸	135*219*137mm
聚光筒重量(不包含镜头)	3.42kg
19°镜头重量	1.94kg
26°镜头重量	1.75kg
36°镜头重量	1.92kg

不同镜头光斑均匀度



Forward

Thank you for purchasing!

Spotlight Attachment Kit is a powerful and practical product specially designed for film and television workers. It is equipped with an adjustable angle and Bowens mount, compatible with various LED lights. It can build an incredibly colorful film scene by creating light effects such as spotlight, follow spot, beam cutting, manual focusing, beam projection and beam modelling. There are 3 types of design, VSA-19K, VSA-26K and VSA-36K, equipped with 19°, 26° and 36° detachable lens respectively.

About the Spotlight Attachment Kit

Multi-slot design supports shutter blade, iris diaphragm, Gobo set and color effects clip.

Flexible U-bracket allows light effect angle be adjusted from 0 to 330°.

Easy focusing to change the edge sharpness of the projection spot and adjust virtual-real effect to inspire creativity for photographers. Gobo holder and color effects clip are standard attachments.

VSA is suitable for Godox VL300,SL150II and other video lights with Bowens mount under 300W lights.

⚠ Warning

⚠ Do not disassemble. Should repairs become necessary, this product must be sent to our Company or an authorized maintenance center.

⚠ This is a precision optical instrument, keep out of reach of children.

⚠ Watch out for high temperature, do not touch when the light is on.

⚠ In the event of malfunction, do not use until professional repair.


⚠ The lens is fragile, please use properly and avoid crash or falling.

⚠ Put the product in ventilated and dry environment when not in use, and keep away from damp.

⚠ Do NOT collocate with LED lights over 300W.

⚠ The Spotlight Attachment is overheating when collocated with LED lights, please wear thick gloves to operate.

Parts



01. Bowens Mount

02. Shutter Blade Slot

03. Iris Diaphragm Slot

04. Gobo Holder Slot

05. Color Effects Set Retainer

06. Focusing Dial


07. Sleeve Knob

08. U-bracket

09. Fixing Groove Pusher

Name	Model	What's in the Box
Spotlight Attachment Kit	VSA-19K	Spotlight Attachment×1 (including a Projection Lens 19°) Gobo Holder×1, Gobo×3, Color Effects Clip×1 Portable Bag CB37×1, Instruction Manual×1
Spotlight Attachment Kit	VSA-26K	Spotlight Attachment×1 (including a Projection Lens 26°) Gobo Holder×1, Gobo×3, Color Effects Clip×1 Portable Bag CB37×1, Instruction Manual×1
Spotlight Attachment Kit	VSA-36K	Spotlight Attachment×1 (including a Projection Lens 36°) Gobo Holder×1, Gobo×3, Color Effects Clip×1 Portable Bag CB37×1, Instruction Manual×1

Packing List



Separately Sold Accessories




GOBO Set for VSA VSA-GS1



GOBO Set for VSA VSA-GS2



GOBO Set for VSA VSA-GS3



GOBO Set for VSA VSA-GS4



Color Temperature Adjustment Set VSA-11T



Color Effects Set VSA-11C



Iris Diaphragm VSA-ID




Lens Portable Bag CB38

Installation and Application


1. Mounted on the tripod

Put the Spotlight Attachment into the sleeve of the tripod, adjust to a proper angle, then turn the sleeve to tighten and fix.




2. Installation of LED Light

Insert the Bowens mount into the buckle of the Spotlight Attachment, then rotate right to tighten it.



3. Disassembly of LED Light (take SL150II as an example)


Hold the SL150II LED light, then rotate left to release it.



Note: Installation and disassembly must be done after the device is powered off.

4. Installation of Iris Diaphragm(Optional)


Loosen the screw beside the iris diaphragm slot with a cross screwdriver in two rounds, slide the iris diaphragm cap and insert the iris diaphragm.



⚠ Note: The iris diaphragm can only be collocated with Godox LED lights of no more than 300w, such as Godox SL60, SL150II, SL200II, VL150, VL200, VL300, FV150, FV200, UL60, UL150, SL100D and SL100Bi. We will not be responsible for any unsatisfied light effects or personal injuries caused by over-heating in case you use other lights.

5. Installation of Color Effects Set(Optional)


Put the Color Effects Set into the Color Effects Clip, push the fixing groove pusher backward and then put the Color Effects Clip into the Color Effects Set Retainer.



⚠ Note: Color Effects Set VSA-11C and VSA-11T can only be collocated with Godox LED lights of no more than 300W, such as Godox SL60, SL150II, SL200II, VL150, VL200, VL300, FV150, FV200, UL60, UL150, SL100D and SL100Bi. We will not be responsible for any Color Effects Set burned or personal injuries in case you use other brands of lights and Color Effects Set.

6. Installation of Gobo

Put the Gobo into the Gobo holder then insert into the slot, press down slightly until fully insertion.



Luminance values with VL300 at different distances




LED Video Light	CCT	Spotlight Attachment	Lens	Illuminance Unit	3m	4m	5m
VL300	5600K 100%	NO	NO	Lux	1380	860	602
				Fc	128.3	79.9	55.9
		YES	Projection Lens 19°	Lux	7530	4040	2400
	100%	YES	Projection Lens 26°	Lux	5130	2830	1720
		YES	Projection Lens 36°	Lux	4200	2330	1430
				Fc	390.3	216.5	132.9

Note: The above luminance values are all average numbers, the illuminance values of different lights vary slightly.

Dimension and Weight

Spotlight Attachment Kit Model	VSA-19K/VSA-26K/VSA-36K
Spotlight Attachment Dimension (excluding Lens)	516*241*196mm
Lens Dimension	135*219*137mm
Spotlight Attachment Weight (excluding Lens)	3.42kg
Projection Lens 19° Weight	1.94kg
Projection Lens 26° Weight	1.75kg
Projection Lens 36° Weight	1.92kg

Beam uniformity of different lens



产品保修

尊敬的用户，本保修卡是申请保修服务的重要凭证，请您配合销售商填写并妥善保管，谢谢！

产品信息	型号	产品条码
用户信息	姓名	联系电话
	通信地址	
销售商信息	名称	
	联系电话	
	通信地址	
	销售日期	
备注		

注：此表应由销售商盖章确认。

适用产品

本文件适用于相关《产品保修信息》(见后面说明)所列产品，其他非属此范围的产品或部件(如促销品、赠品及其他出厂后附加的部件等)不在此保修承诺内。

保修期

产品及部件的相应保修期按相关的《产品保修信息》执行。保修期自产品首次购买日起算，购买日以购买产品时保修卡登记日期为准。

如何获得保修服务

您可直接与产品销售商或授权服务机构联系，也可拨打神牛产品售后服务电话，与我们联系，由我们的服务人员为您安排服务。申请保修时，您应提供有效的保修卡作为保修凭证，方可获得保修。如您不能提供有效的保修卡，则在我们确认产品或部件属于保修范围的情况下，也可以为您提供保修，但这不作为我们的义务。

不适用保修的情况

如产品存在下列情况，本文件项下的保证和服务将不适用 ①产品或部件超过相应保修期；②错误或不适当使用、维护或 保管导致的故障或损坏，如：不当搬运；非按产品合理预期用途使用；不当插拔外接设备；跌落或外力挤压；接触或暴露于不适当温度、溶剂、酸碱、水浸或潮湿环境；③由非神牛授权机构或人员安装、修理、更改、添加或拆卸造成的故障或损坏；④产品或部件原有识别信息被修改变更或除去；⑤无有效保修卡；⑥使用非合法授权、非标准或非公开发行的软件造成的故障或损坏；⑦因不可抗力或意外事件造成的故障或损坏；⑧其他非因产品本身质量问题导致的故障或损坏。遇上述情况，您应向相关责任方寻求解决，神牛对此不承担任何责任。因非在保修期或保修范围内的部件、附件或软件导致产品不能正常使用的，不是保修范围内的故障。产品使用过程中正常的脱色，磨损和消耗，不是保修范围内的故障。

产品保修和服务支持信息

产品的保修期和服务类型按以下《产品保修信息》执行：

产品类别	选件名称	保修期(月)	保修服务类型
部件	电路板	12	客户送修
	电池	3	客户送修
	充电器、电源线，同步线等 带电性能的部件。	12	客户送修
其他	如闪光管、造型灯泡、外壳、 保护罩、锁紧装置、包装等。	无	无保修

神牛产品售后服务电话 0755-29609320-8062

Warranty

Dear customers, as this warranty card is an important certificate to apply for our maintenance service, please fill in the following form in coordination with the seller and safe-keep it. Thank you!

Product Information	Model	Product Code Number
Customer Information	Name	Contact Number
	Address	
Seller Information	Name	
	Contact Number	
	Address	
	Date of Sale	
Note:		

Note: This form shall be sealed by the seller.

How to Get the Maintenance Service

If maintenance service is needed, you can directly contact the product distributor or authorized service institutions. You can also contact the Godox after-sale service call and we will offer you service. When applying for maintenance service, you should provide valid warranty card. If you cannot provide valid warranty card, we may offer you maintenance service once confirmed that the product or accessory is involved in the maintenance scope, but that shall not be considered as our obligation.

Inapplicable Cases

The guarantee and service offered by this document are not applicable in the following cases: ①. The product or accessory has expired its warranty period; ②. Breakage or damage caused by inappropriate usage, maintenance or preservation, such as improper packing, improper usage, improper plugging in/out external equipment, falling off or squeezing by external force, contacting or exposing to the improper temperature, solvent, acid, base, flooding and damp environments, etc; ③. Breakage or damage caused by non-authorized institution or staff in the process of installation, maintenance, alternation, addition and detachment; ④. The original identifying information of product or accessory is modified, alternated, or removed; ⑤. No valid warranty card; ⑥. Breakage or damage caused by using illegally authorized, nonstandard or non-public released software; ⑦. Breakage or damage caused by force majeure or accident; ⑧. Breakage or damage that could not be attributed to the product itself. Once met these situations above, you should seek solutions from the related responsible parties and Godox assumes no responsibility. The damage caused by parts, accessories and software that beyond the warranty period or scope is not included in our maintenance scope. The normal discoloration, abrasion and consumption are not the breakage within the maintenance scope.

Applicable Products

The document applies to the products listed on the Product Maintenance Information (see below for further information). Other products or accessories (e.g. promotional items, giveaways and additional accessories attached, etc.) are not included in this warranty scope.

Warranty Period

The warranty period of products and accessories is implemented according to the relevant Product Maintenance Information. The warranty period is calculated from the day(purchase date) when the product is bought for the first time, And the purchase date is considered as the date registered on the warranty card when buying the product.